

## Time setting

### Set



### Go



- A Normal position of the crown
- C Position for setting the time

To set the time, pull the crown out to position **C** and turn clockwise or anticlockwise. After resetting has been completed, press the crown back to position **A**.

## Date

### Set




### Go




To set the date, pull the crown out to position **B**, and turn anticlockwise. After resetting has been completed, press the crown back to position **A**.

## Display



- A Minutes counter (60 minutes)
- B Seconds counter
- C  $\frac{1}{10}$  second counter
- D Push-button
- E Crown
- F Push-button
- G Hours hand
- H Seconds hand
- I Minutes hand

## Timing mode




### Press...


1. The upper push-button to start the chronograph.
2. Once again to read the elapsed time.
3. The lower push-button to reset.

### Split time


Go




Stop




Go



Stop



Reset




#### Press...

1. The upper push-button to start the chronograph.
2. The lower push-button to read the intermediary time.
3. Once again to continue (repeat the last two actions as many times as you wish to read the intermediary time while the chrono carries on).
4. The upper push-button to stop finally.
5. The lower push-button to reset.

### Add Functions

Start



Read




Restart



Read



Reset




#### Press...


1. The upper push-button to start.
2. Press the upper push-button to read the first time.
3. Press the upper push-button to restart the chronograph.
4. Press the upper push-button to read the additional time (repeat these two steps as many times as you wish).
5. Press the lower push-button to reset.

## Tachometer


**Go**



**Stop**



**Reset**





Measure the speed Base 100 or 1000 m.

### Press...

1. The upper push-button when an action starts.
2. Once again to stop after a distance of 100 or 1000 m. Read the speed indicated by the 60 seconds counter on the tachometer scale (km/h = kph).
3. The lower push-button to reset.

## Readjustment



Adjusting the chronograph (ex: after battery change or a hard shock)

1. Pull the crown to position **B**.
2. Press the upper button to reach the position 12 h 00 with the hand of the  $\frac{1}{10}$  sec. counter.
3. Pull the lower button to reach the position 12 h 00 with the hand of the seconds.
4. Pull the crown to the position **C**.
5. Press the upper button to reach the position 12 h 00 with the hand of the minutes counters.
6. Press the crown to position **A**.